

ICF-SW15

SERVICE MANUAL

本资料由OKXIA视听皮带资源库www.okxia.cn提供



US Model
Canadian Model
AEP Model
UK Model
E Model
Australian Model
Tourist Model

SPECIFICATIONS

Frequency range	FM: 76–108 MHz (US, Canadian, E, Australian, Tourist models) 87.6–107.5 MHz (AEP, UK, Italian, Saudi Arabia models)
	IF: 10.7 MHz
	SW1: 5.775–6.425 MHz
	SW2: 6.875–7.525 MHz
	SW3: 9.375–10.025 MHz
	SW4: 11.615–12.265 MHz
	SW5: 15.00–15.65 MHz
	SW6: 17.50–18.15 MHz
	SW7: 21.325–21.975 MHz
	1st IF: 10.7 MHz
	2nd IF: 455 kHz
	MW: 530–1,710 kHz (US, Canadian, E, Australian, Tourist models) 531–1,602 kHz (AEP, UK, Italian, Saudi Arabia models)
	IF: 455 kHz
Antenna	FM/SW: Telescopic antenna MW: Built-in ferrite bar antenna
Speaker	Approx. 6.6 cm (2½ inches) dia. 4Ω
Power output	260 mW (at 10% harmonic distortion)
Output	Earphone jack (minijack)
Power requirements	4.5 V DC, three R6 (size AA) batteries DC IN 4.5 V jack accepts: AC power adaptor AC-E45M (not supplied) Car battery cord DCC-E145L (not supplied)
Battery life	Approx. 27 hours with Sony SUM-3 (NS)
Dimensions	Approx. 165 × 99 × 35 mm (w/h/d) (6½ × 4 × 1½ inches)
Weight	Approx. 380 g (13.4 oz) incl. batteries
Supplied accessories	Carrying case (1), Short wave guide (1)

Accessories not supplied AC power adaptor *AC-E45M
Car battery cord DCC-E145L
LW/MW/SW wide range antenna AN-1
Earphone ME-81

* The voltage of power supply is different depending on the country. Please buy an AC power adaptor in the country where the radio is to be used.

Design and specifications subject to change without notice.




Features

- FM/MW/SW1-7 9 band receiver with high sensitivity and selectivity.
- Band spread system enables you to easily tune in SW stations.
- Dual conversion circuit effectively reduces SW bands interference from other SW stations.

NOTE: ALL CORRECTIONS AND SUPPLEMENTS ARE ATTACHED TO THE BACK OF THE MANUAL.

Notes


- When the AC power adaptor is not used, be sure to unplug it both from the DC IN 4.5 V jack and from a wall outlet.
- Use only the AC power adaptor AC-E45M (not supplied). Do not use any other AC power adaptor.



Polarity of the plug

FM/MW/SW1-7
9 BAND RECEIVER
SONY®

Parts Identification






- 1 Telescopic antenna
- 2 VOLUME control
- 3 TONE (MUSIC/NEWS) selector
MUSIC: for listening to the music
NEWS: for listening to news, etc.
- 4 Ⓜ (earphone) jack
- 5 DC IN 4.5 V (external power input) jack
- 6 Speaker
- 7 Battery compartment (bottom)
- 8 OFF (power off) button
- 9 POWER ON/BAND FM/MW/SW buttons and indicators
When you press one of the buttons, the unit is turned on and the indicator lights up.
- 10
- 11 Hand strap
- 12 HOLD switch
Slide it in the direction of the arrow (HOLD):
When listening, to avoid accidental change of the functions.
When not using, to prevent accidental pressing to turn the power on.
- 13 Dial scales
- 14 TUNING control
- 15 TUNE (tuning) Indicator
The indicator lights up when a signal is received.
- 16 Stand (rear)

B How to use the stand

SECTION 1 DIAL POINTER SETTING

Note: Follow the assembly procedure in the numerical order given.




- 7 First, turn the tuning shaft fully in the arrow A direction. Move only the dial pointer in the arrow B direction and set it on the scratched lines on the dial scale plate. Apply suitable locking compound to C portion.

Parts Identification

- 
- 1. Main body
 - 2. Main body cover
 - 3. Main body cover latch
 - 4. Main body cover latch pin
 - 5. Main body cover latch pin
 - 6. Main body cover latch pin
 - 7. Main body cover latch pin
 - 8. Main body cover latch pin
 - 9. Main body cover latch pin
 - 10. Main body cover latch pin
 - 11. Main body cover latch pin
 - 12. Main body cover latch pin
 - 13. Main body cover latch pin
 - 14. Main body cover latch pin
 - 15. Main body cover latch pin
 - 16. Main body cover latch pin
 - 17. Main body cover latch pin
 - 18. Main body cover latch pin

SECTION 1 DIAL POINTER SETTING

Shown: Dialing the main body into the main body cover.




1. Check the dial pointer is set to 0. 2. Tighten the main body. 3. Rotate the main body cover. 4. Tighten the main body cover. 5. Check the dial pointer is set to 0.

SECTION 2 ELECTRICAL ADJUSTMENTS

【MW SECTION】

BAND switch : MW

AM rf signal
generator



put the lead-wire
antenna close to
the set

30% amplitude
modulation by 400Hz signal
Output level : as low as possible

【SW SECTION】

BAND switch : SW

AM rf signal
generator



7pF
ANT IN

30% amplitude modulation
by 400Hz signal
Output level : as low as possible

【FM SECTION】


BAND switch : FM

FM rf signal
generator



0.01μF
ANT IN

400Hz, 30% FM modulation
frequency deviation ± 22.5 kHz
Output level : as low as possible



- Repeat the procedures in each adjustment several times, and the frequency coverage and tracking adjustments should be finally done by the trimmer capacitors.
- SW1 to 7 Tracking Adjustment frequencies are in a line on the scale.
Therefore, on adjusting, first SW1 6.1 MHz and after adjust SW2 to 7 Tracking without moving the dial pointer.

() : AEP, UK, Germany, Italian, Saudi Arabian model

MW IF ADJUSTMENT

Adjust for a maximum reading on VTVM.

T3	455 kHz
----	---------

MW FREQUENCY COVERAGE ADJUSTMENT

Adjust for a maximum reading on VTVM.

L15	520 kHz
-----	---------

CT2-3	1750 kHz (1650 kHz)
-------	---------------------

MW TRACKING ADJUSTMENT

Adjust for a maximum reading on VTVM.

L12	620 kHz
-----	---------

CT2-4	1400 kHz
-------	----------

SW IF (1) ADJUSTMENT

Adjust for a maximum reading on VTVM.

T1	10.6 MHz
----	----------

SW IF (2) ADJUSTMENT

Adjust for a maximum reading on VTVM.

T2	455 kHz
----	---------

SW1 FREQUENCY COVERAGE ADJUSTMENT

Adjust for a maximum reading on VTVM.

T4	5.75 MHz
----	----------

CT1	6.45 MHz
-----	----------

SW1 TRACKING ADJUSTMENT

Adjust for a maximum reading on VTVM.

L1	6.1 MHz
----	---------

SW2 TRACKING ADJUSTMENT

Adjust for a maximum reading on VTVM.

L2	7.2 MHz
----	---------

SW3 TRACKING ADJUSTMENT

Adjust for a maximum reading on VTVM.

L3	9.7 MHz
----	---------

SW4 TRACKING ADJUSTMENT

Adjust for a maximum reading on VTVM.

L4	11.94 MHz
----	-----------

SECTION 2 ELECTRICAL ADJUSTMENTS

[MW SECTION]

SWR1 controls - SWR

Add 4 signal generator



put the load into
circuit when
to be set

SWR1 amplitude modulation
to 100% signal
Output level 1 at 100% power

[SW SECTION]

SWR2 controls - SWR

Add 4 signal generator



SWR

ANT IN

SWR2 amplitude modulation
to 100% signal
Output level 1 at 100% power

[FM SECTION]

SWR3 controls - FM

FM 4 signal generator



FM

ANT IN

SWR3, SWR4, FM modulation
frequency 100% signal
Output level 1 at 100% power



100V

Adjust the potentiometer in each adjustment several times,
and the frequency coverage and tracking adjustments
should be finally done by the voltage regulator.

SWR1 to F Tracking Adjustment: Response set to a 100%
modulation.

Then, in adjusting, first FWS 6.1 MHz and after
that FWS to F Tracking without moving the dial
pointer.

(3) : AMP, UK, Germany, Italia, South Arabian model

MW F ADJUSTMENT

Adjust for a maximum reading on VTVM.

TR 400 kHz

MW FREQUENCY COVERAGE ADJUSTMENT

Adjust for a maximum reading on VTVM.

L1 6.1 MHz

OTL 170 kHz (200 kHz)

MW TRACKING ADJUSTMENT

Adjust for a maximum reading on VTVM.

L1 6.1 MHz

OTL 170 kHz

SW F ADJUSTMENT

Adjust for a maximum reading on VTVM.

TR 400 kHz

SW FREQUENCY COVERAGE ADJUSTMENT

Adjust for a maximum reading on VTVM.

TR 400 kHz

SW TRACKING ADJUSTMENT

Adjust for a maximum reading on VTVM.

TR 400 kHz

OTL 170 kHz

FM TRACKING ADJUSTMENT

Adjust for a maximum reading on VTVM.

L1 6.1 MHz

FM TRACKING ADJUSTMENT

Adjust for a maximum reading on VTVM.

L1 6.1 MHz

FM TRACKING ADJUSTMENT

Adjust for a maximum reading on VTVM.

L1 6.1 MHz

FM TRACKING ADJUSTMENT

Adjust for a maximum reading on VTVM.

L1 6.1 MHz

SW5 TRACKING ADJUSTMENT	
Adjust for a maximum reading on VTVM.	
L5	15.325 MHz


SW6 TRACKING ADJUSTMENT	
Adjust for a maximum reading on VTVM.	
L6	17.825 MHz

SW7 TRACKING ADJUSTMENT	
Adjust for a maximum reading on VTVM.	
L7	21.65 MHz

FM FREQUENCY COVERAGE ADJUSTMENT	
Adjust for a maximum reading on VTVM.	
L14	75.0 MHz (87.35 MHz)
CT2-2	109.5 MHz (108.05 MHz)

FM TRACKING ADJUSTMENT	
Adjust for a maximum reading on VTVM.	
L13	80 MHz (87.35 MHz)
CT2-1	104 MHz (108.05 MHz)

ADJUSTMENT LOCATION



SWR TRACKING ADJUSTMENT	
Adjust for a maximum reading on VTVM	
L4	14.550 MHz


SWR TRACKING ADJUSTMENT	
Adjust for a maximum reading on VTVM	
L6	17.000 MHz

SWR TRACKING ADJUSTMENT	
Adjust for a maximum reading on VTVM	
L7	20.00 MHz

FM FREQUENCY COVERAGE ADJUSTMENT	
Adjust for a maximum reading on VTVM	
L44	76.0 MHz (75.00 MHz)
CT9-2	80.0 MHz (79.00 MHz)

FM TRACKING ADJUSTMENT	
Adjust for a maximum reading on VTVM	
L45	80 MHz (79.00 MHz)
CT9-1	84 MHz (83.00 MHz)

ADJUSTMENT LOCATION



SECTION 4 EXPLODED VIEW

NOTE:

- -XX,-X mean standardized parts, so they may have some difference from the original one.

- Color indication of Appearance Parts.

Example:


KNOB,BALANCE (WHITE) ... (RED)

↑ ↑
 Parts Cabinet's
 Color Color

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- The mechanical parts with no reference number in the exploded views are not supplied.

- Hardware (# mark) list is given in the last of this parts list.



Ref. No.	Part No.	Description	Remark
1	X-3365-618-1	CABINET (FRONT) ASSY (US, Canadian, E, TOURIST, Australian)	
1	X-3365-619-1	CABINET (FRONT) ASSY (AEP, Germany, UK, Italian, Saudi Arabia)	
2	3-380-912-01	BUTTON (OFF)	
3	3-380-923-01	BAND, BUTTON	
4	7-685-131-19	SCREW +P 2.6X4 TYPE2 NON-SLIT	
5	3-880-990-00	SCREW (1.7X3), FLAT, (+) SPECIAL	
6	3-382-003-01	GEAR (B), TUNING CAPACITOR	
7	3-380-914-01	GEAR (A), TUNING CAPACITOR	
8	3-380-915-01	SCALE, DIAL	
9	3-382-325-01	SPRING (SP)	
10	3-380-917-01	KNOB (HOLD)	
11	3-380-921-01	KNOB (SW)	
12	3-380-911-01	INDICATOR	
* 13	3-380-926-01	CHASSIS	
14	3-380-913-01	KNOB (VOL)	
* 15	A-3679-409-A	MAIN BOARD, COMPLETE) (AEP, Germany, UK, Italian, Saudi Arabia)	
* 15	A-3679-410-A	MAIN BOARD, COMPLETE (US, Canadian, E, TOURIST, Australian)	

Ref. No.	Part No.	Description	Remark
16	3-382-322-01	TERMINAL (MINUS), BATTERY	
17	3-382-005-01	PLATE, CONTACT, ANTENNA	
18	7-627-556-37	SCREW, PRECISION +P2. 6X4 TYPE 1	
19	3-380-918-01	STAND	
20	7-685-138-19	SCREW +P 2.6X16 TYPE2 NON-SLIT	
21	3-380-925-01	CABINET (REAR)	
23	3-380-922-01	LID, BATTERY CASE	
24	3-382-006-01	TERMINAL, BATTERY	
25	3-900-151-01	SPRING, RING	
26	3-380-908-01	SHAFT (TUN)	
27	3-380-909-01	KNOB (TUN)	
29	3-900-157-01	PULLEY	
30	3-382-324-01	BELT (TUN)	
31	3-380-910-01	GEAR, MIDWAY	
32	3-380-916-01	POINTER	
33	3-383-019-01	STRAP, HAND	
ANT1	1-501-543-11	ANTENNA, TELESCOPIC	
SP1	1-544-758-11	SPEAKER (6.6CM)	

SECTION 5 ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms.
METAL: Metal-film resistor.
METAL OXIDE: Metal oxide-film resistor.
F: nonflammable
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u: μ , for example:
uA...: μ A... uPA...: μ PA...
uPB...: μ PB... uPC...: μ PC... uPD...: μ PD...
- CAPACITORS
uF: μ F
- COILS
uH: μ H

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-3679-409-A	MAIN BOARD, COMPLETE (AEP, Germany, UK, Italian, Saudi Arabia)		C17	1-163-229-11	CERAMIC CHIP 12PF	5% 50V
*	A-3679-410-A	MAIN BOARD, COMPLETE (US, Canadian, E, TOURIST, Australian)		C18	1-164-232-11	CERAMIC CHIP 0.01uF	50V
		*****		C19	1-164-004-11	CERAMIC CHIP 0.1uF	10% 25V
				C20	1-164-004-11	CERAMIC CHIP 0.1uF	10% 25V
				C21	1-126-163-11	ELECT 4.7uF	20% 50V
*	3-380-924-01	HOLDER		C23	1-164-232-11	CERAMIC CHIP 0.01uF	50V
		< BAND PASS FILTER >		C24	1-164-232-11	CERAMIC CHIP 0.01uF	50V
BPF1	1-239-359-11	FILTER, BAND PASS (AEP, Germany, UK, Italian, Saudi Arabia)		C25	1-126-163-11	ELECT 4.7uF	20% 50V
BPF1	1-239-360-11	FILTER, BAND PASS (US, Canadian, E, TOURIST, Australian)		C26	1-126-163-11	ELECT 4.7uF	20% 50V
		< CAPACITOR >		C27	1-126-096-11	ELECT 10uF	20% 35V
C1	1-164-232-11	CERAMIC CHIP 0.01uF	50V	C28	1-163-037-11	CERAMIC CHIP 0.022uF	10% 25V
C2	1-164-232-11	CERAMIC CHIP 0.01uF	50V	C29	1-124-234-00	ELECT 22uF	20% 16V
C3	1-164-232-11	CERAMIC CHIP 0.01uF	50V	C30	1-124-472-11	ELECT 470uF	20% 10V
C5	1-163-009-11	CERAMIC CHIP 0.001uF	10% 50V	C31	1-164-004-11	CERAMIC CHIP 0.1uF	10% 25V
C6	1-163-095-00	CERAMIC CHIP 12PF	5% 50V	C32	1-164-346-11	CERAMIC CHIP 1uF	16V
C7	1-126-154-11	ELECT 47uF	20% 6.3V	C33	1-124-442-00	ELECT 330uF	20% 6.3V
C8	1-164-232-11	CERAMIC CHIP 0.01uF	50V	C34	1-126-154-11	ELECT 47uF	20% 6.3V
C9	1-164-232-11	CERAMIC CHIP 0.01uF	50V	C35	1-163-003-11	CERAMIC CHIP 330PF	10% 50V
C10	1-164-232-11	CERAMIC CHIP 0.01uF	50V	C36	1-163-001-11	CERAMIC CHIP 220PF	10% 50V
C11	1-164-232-11	CERAMIC CHIP 0.01uF	50V	C37	1-163-113-00	CERAMIC CHIP 68PF	5% 50V
C13	1-164-232-11	CERAMIC CHIP 0.01uF	50V	C38	1-163-111-00	CERAMIC CHIP 56PF	5% 50V
C14	1-163-083-00	CERAMIC CHIP 1PF	50V	C39	1-164-232-11	CERAMIC CHIP 0.01uF	50V
C15	1-163-100-00	CERAMIC CHIP 20PF	5% 50V	C40	1-163-809-11	CERAMIC CHIP 0.047uF	10% 25V
		(AEP, Germany, UK, Italian, Saudi Arabia)		C41	1-163-111-00	CERAMIC CHIP 56PF	5% 50V
C15	1-163-102-00	CERAMIC CHIP 24PF	5% 50V	C42	1-163-377-11	CERAMIC CHIP 100PF	5% 50V
		(US, Canadian, E, TOURIST, Australian)		C43	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
C16	1-163-099-00	CERAMIC CHIP 18PF	5% 50V	C44	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
		(US, Canadian, E, TOURIST, Australian)		C45	1-126-096-11	ELECT 10uF	20% 35V
C16	1-163-104-00	CERAMIC CHIP 30PF	5% 50V	C49	1-126-154-11	ELECT 47uF	20% 6.3V
		(AEP, Germany, UK, Italian, Saudi Arabia)		C50	1-126-163-11	ELECT 4.7uF	20% 50V
				C52	1-164-232-11	CERAMIC CHIP 0.01uF	50V
				C53	1-164-232-11	CERAMIC CHIP 0.01uF	50V
				C54	1-164-232-11	CERAMIC CHIP 0.01uF	50V
				C55	1-164-232-11	CERAMIC CHIP 0.01uF	50V
				C56	1-164-232-11	CERAMIC CHIP 0.01uF	50V

MAIN

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C57	1-164-232-11	CERAMIC CHIP 0.01uF	50V	D11	8-719-812-41	LED TLR124	
C58	1-162-638-11	CERAMIC CHIP 1uF	16V	D12	8-719-812-41	LED TLR124	
C59	1-164-004-11	CERAMIC CHIP 0.1uF	10% 25V	D13	8-719-812-41	LED TLR124	
C60	1-164-232-11	CERAMIC CHIP 0.01uF	50V	D14	8-719-812-41	LED TLR124	
C61	1-124-234-00	ELECT 22uF	20% 16V	D15	8-719-800-76	DIODE 1SS226	
C62	1-164-232-11	CERAMIC CHIP 0.01uF	50V	< IC >			
C63	1-126-154-11	ELECT 47uF	20% 6.3V	IC1	8-752-035-29	IC CXA1019S	
C64	1-164-232-11	CERAMIC CHIP 0.01uF	50V	IC2	8-759-979-91	IC CF77392NS	
C65	1-163-090-00	CERAMIC CHIP 7PF	50V	IC3	8-759-937-61	IC S-81230AG	
C66	1-162-638-11	CERAMIC CHIP 1uF	16V	< JACK >			
C67	1-163-020-00	CERAMIC CHIP 0.0082uF	10% 50V	J1	1-563-836-21	JACK (EARPHONE)	
C68	1-163-023-00	CERAMIC CHIP 0.015uF	5% 50V	J2	1-580-681-21	JACK, DC (POLARITY UNIFIED TYPE)	
C69	1-163-022-00	CERAMIC CHIP 0.012uF	10% 50V	< COIL >			
C70	1-163-016-00	CERAMIC CHIP 0.0039uF	10% 50V	L1	1-402-334-11	COIL (ANT)	
C71	1-163-010-11	CERAMIC CHIP 0.0012uF	10% 50V	L2	1-402-332-11	COIL (ANT)	
C74	1-163-085-00	CERAMIC CHIP 2PF	50V	L3	1-402-397-11	COIL (ANT)	
		(AEP, Germany, UK, Italian, Saudi Arabia)		L4	1-402-331-11	COIL (ANT)	
C74	1-163-086-00	CERAMIC CHIP 3PF	50V	L5	1-406-261-11	COIL (OSC)	
		(US, Canadian, E, TOURIST, Australian)		L6	1-402-433-11	COIL (ANT)	
C75	1-126-096-11	ELECT 10uF	20% 35V	L7	1-402-330-11	COIL (ANT)	
C76	1-163-117-00	CERAMIC CHIP 100PF	5% 50V	L8	1-414-021-11	INDUCTOR 0.82uH	
C77	1-164-004-11	CERAMIC CHIP 0.1uF	10% 25V	L9	1-414-027-11	INDUCTOR 8.2uH	
C78	1-164-232-11	CERAMIC CHIP 0.01uF	50V	L10	1-410-967-11	INDUCTOR 2.2uH	
C79	1-163-088-00	CERAMIC CHIP 5PF	50V	L11	1-410-322-11	INDUCTOR 3.3uH	
< FILTER >				L12	1-402-628-11	ANTENNA, FERRITE-ROD (MW)	
CF1	1-567-097-61	FILTER, CERAMIC				(AEP, Germany, UK, Italian, Saudi Arabia)	
CF2	1-577-647-11	FILTER, CERAMIC		L12	1-402-633-11	ANTENNA, FERRITE-ROD (MW)	
CF3	1-577-047-11	FILTER, CERAMIC				(US, Canadian, E, TOURIST, Australian)	
< TRIMMER >				L13	1-460-351-11	COIL (WITH CORE)	
CT1	1-141-304-21	CAP, TRIMMER 10PF		L14	1-460-348-11	COIL (WITH CORE)	
< VARIABLE CAPACITOR >						(AEP, Germany, UK, Italian, Saudi Arabia)	
CV2	1-151-649-11	CAP, VARIABLE		L14	1-460-349-11	COIL (WITH CORE)	
CT2		(AEP, Germany, UK, Italian, Saudi Arabia)				(US, Canadian, E, TOURIST, Australian)	
CV2	1-151-650-11	CAP, VARIABLE		L15	1-406-255-11	COIL (OSC)	
CT2		(US, Canadian, E, TOURIST, Australian)		< TRANSISTOR >			
< DIODE >				Q1	8-729-117-83	TRANSISTOR 2SK160A-K25	
D1	8-719-123-79	DIODE 1SS279		Q2	8-729-116-64	TRANSISTOR 2SK508-K51	
D2	8-719-123-79	DIODE 1SS279		Q3	8-729-220-93	TRANSISTOR 2SK209-G	
D3	8-719-123-79	DIODE 1SS279		Q4	8-729-102-07	TRANSISTOR 2SC2223-F13	
D4	8-719-800-76	DIODE 1SS226		Q5	8-729-102-07	TRANSISTOR 2SC2223-F13	
D5	8-719-400-18	DIODE MA152WK		Q6	8-729-402-84	TRANSISTOR XN4601	
D10	8-719-800-76	DIODE 1SS226					

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
Q7	8-729-402-13	TRANSISTOR	XN1501	R42	1-216-053-00	METAL CHIP	1.5K 5% 1/10W
Q9	8-729-807-87	TRANSISTOR	2SB1295-UL6	R43	1-216-041-00	METAL CHIP	470 5% 1/10W
Q10	8-729-402-84	TRANSISTOR	XN4601	R44	1-216-081-00	METAL CHIP	22K 5% 1/10W
Q13	8-729-120-28	TRANSISTOR	2SC1623-LSL6	R45	1-216-049-00	METAL CHIP	1K 5% 1/10W
Q15	8-729-402-84	TRANSISTOR	XN4601	R46	1-216-246-00	METAL GLAZE	100K 5% 1/8W
				R47	1-216-246-00	METAL GLAZE	100K 5% 1/8W
R1	1-216-057-00	METAL CHIP	2.2K 5% 1/10W	R48	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R2	1-216-091-00	METAL CHIP	56K 5% 1/10W	R49	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R3	1-216-041-00	METAL CHIP	470 5% 1/10W	R50	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R4	1-216-040-00	METAL GLAZE	430 5% 1/10W	R51	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R5	1-216-097-00	METAL CHIP	100K 5% 1/10W				
				R52	1-216-113-00	METAL CHIP	470K 5% 1/10W
				R53	1-216-073-00	METAL CHIP	10K 5% 1/10W
R6	1-216-059-00	METAL CHIP	2.7K 5% 1/10W	R54	1-216-178-00	METAL GLAZE	150 5% 1/8W
R7	1-216-041-00	METAL CHIP	470 5% 1/10W	R56	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R8	1-216-065-00	METAL CHIP	4.7K 5% 1/10W	R57	1-216-053-00	METAL CHIP	1.5K 5% 1/10W
R9	1-216-063-00	METAL CHIP	3.9K 5% 1/10W				
R10	1-216-063-00	METAL CHIP	3.9K 5% 1/10W	R58	1-216-089-00	METAL CHIP	47K 5% 1/10W
				R59	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R11	1-216-073-00	METAL CHIP	10K 5% 1/10W	R60	1-216-041-00	METAL CHIP	470 5% 1/10W
R12	1-216-057-00	METAL CHIP	2.2K 5% 1/10W	R61	1-216-190-00	METAL GLAZE	470 5% 1/8W
R13	1-216-082-00	METAL GLAZE	24K 5% 1/10W	R62	1-216-190-00	METAL GLAZE	470 5% 1/8W
R14	1-216-049-00	METAL CHIP	1K 5% 1/10W				
R15	1-216-067-00	METAL CHIP	5.6K 5% 1/10W	R63	1-216-296-00	METAL CHIP	0 5% 1/8W
				R64	1-216-113-00	METAL CHIP	470K 5% 1/10W
R16	1-216-295-00	METAL CHIP	0 5% 1/10W	R65	1-216-089-00	METAL CHIP	47K 5% 1/10W
R18	1-216-037-00	METAL CHIP	330 5% 1/10W	R66	1-216-053-00	METAL CHIP	1.5K 5% 1/10W
R19	1-216-077-00	METAL CHIP	15K 5% 1/10W	R67	1-216-097-00	METAL CHIP	100K 5% 1/10W
R20	1-216-105-00	METAL CHIP	220K 5% 1/10W				
R21	1-216-049-00	METAL CHIP	1K 5% 1/10W	R68	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
				R69	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R22	1-216-049-00	METAL CHIP	1K 5% 1/10W	R70	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R23	1-216-114-00	METAL GLAZE	510K 5% 1/10W	R71	1-216-017-00	METAL CHIP	47 5% 1/10W
R24	1-216-105-00	METAL CHIP	220K 5% 1/10W	R72	1-216-097-00	METAL CHIP	100K 5% 1/10W
R25	1-216-091-00	METAL CHIP	27K 5% 1/10W				
R26	1-216-049-00	METAL CHIP	1K 5% 1/10W	R73	1-216-296-00	METAL CHIP	0 5% 1/8W
				R74	1-216-296-00	METAL CHIP	0 5% 1/8W
R27	1-216-043-00	METAL CHIP	560 5% 1/10W	R75	1-216-296-00	METAL CHIP	0 5% 1/8W
R28	1-216-058-00	METAL GLAZE	2.4K 5% 1/10W	R76	1-216-296-00	METAL CHIP	0 5% 1/8W
R29	1-216-105-00	METAL CHIP	220K 5% 1/10W	R77	1-216-296-00	METAL CHIP	0 5% 1/8W
R30	1-216-091-00	METAL CHIP	56K 5% 1/10W				
R31	1-216-057-00	METAL CHIP	2.2K 5% 1/10W	R78	1-216-296-00	METAL CHIP	0 5% 1/8W
				R79	1-216-296-00	METAL CHIP	0 5% 1/8W
R32	1-216-081-00	METAL CHIP	22K 5% 1/10W	R80	1-216-296-00	METAL CHIP	0 5% 1/8W
R33	1-216-198-00	METAL CHIP	1K 5% 1/8W	R81	1-216-295-00	METAL CHIP	0 5% 1/10W
R34	1-216-049-00	METAL CHIP	1K 5% 1/10W	R82	1-216-296-00	METAL CHIP	0 5% 1/8W
R35	1-216-025-00	METAL CHIP	100 5% 1/10W				
R36	1-216-059-00	METAL CHIP	2.7K 5% 1/10W	R83	1-216-296-00	METAL CHIP	0 5% 1/8W
				R84	1-216-296-00	METAL CHIP	0 5% 1/8W
R37	1-216-689-11	METAL CHIP	39K 0.5% 1/10W	R85	1-216-296-00	METAL CHIP	0 5% 1/8W
R38	1-216-065-00	METAL CHIP	4.7K 5% 1/10W	R86	1-216-296-00	METAL CHIP	0 5% 1/8W
R39	1-216-065-00	METAL CHIP	4.7K 5% 1/10W	R87	1-216-296-00	METAL CHIP	0 5% 1/8W
R40	1-216-097-00	METAL CHIP	100K 5% 1/10W				
R41	1-216-029-00	METAL CHIP	150 5% 1/10W	R88	1-216-296-00	METAL CHIP	0 5% 1/8W
				R89	1-216-296-00	METAL CHIP	0 5% 1/8W
				R90	1-216-296-00	METAL CHIP	0 5% 1/8W
				R91	1-216-296-00	METAL CHIP	0 5% 1/8W

[illegible][illegible]

MAIN

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R92	1-216-296-00	METAL CHIP	0 5%	1/8W			
R93	1-216-296-00	METAL CHIP	0 5%	1/8W			
R94	1-216-296-00	METAL CHIP	0 5%	1/8W			
R95	1-216-296-00	METAL CHIP	0 5%	1/8W			
R96	1-216-296-00	METAL CHIP	0 5%	1/8W			
R97	1-216-295-00	METAL CHIP	0 5%	1/10W			
R98	1-216-295-00	METAL CHIP	0 5%	1/10W			
R99	1-216-295-00	METAL CHIP	0 5%	1/10W			
R100	1-216-295-00	METAL CHIP	0 5%	1/10W			
R101	1-216-295-00	METAL CHIP	0 5%	1/10W			
R102	1-216-295-00	METAL CHIP	0 5%	1/10W			
R103	1-216-295-00	METAL CHIP	0 5%	1/10W			
R104	1-216-295-00	METAL CHIP	0 5%	1/10W			
R105	1-216-296-00	METAL CHIP	0 5%	1/8W			
R106	1-216-295-00	METAL CHIP	0 5%	1/10W			
R107	1-216-296-00	METAL CHIP	0 5%	1/8W			
R108	1-216-295-00	METAL CHIP	0 5%	1/10W			
R109	1-216-295-00	METAL CHIP	0 5%	1/10W			
R110	1-216-295-00	METAL CHIP	0 5%	1/10W			
R111	1-216-295-00	METAL CHIP	0 5%	1/10W			
		< VARIABLE RESISTOR >					
RV1	1-238-555-11	RES, VAR, CARBON 50K (VOLUME)					
		< SWITCH >					
S1	1-554-979-11	SWITCH, SLIDE (BAND SELECTOR)					
S2	1-572-761-31	SWITCH, SLIDE (TONE)					
S3	1-553-510-00	SWITCH, SLIDE (HOLD)					
S4	1-692-016-11	SWITCH, KEY BOARD (PW)					
S5	1-692-016-11	SWITCH, KEY BOARD (MW)					
S6	1-692-016-11	SWITCH, KEY BOARD (SW)					
S7	1-692-016-11	SWITCH, KEY BOARD (OFF)					
		< TRANSFORMER >					
T1	1-404-764-11	TRANSFORMER, IF					
T2	1-404-362-61	TRANSFORMER, IF					
T3	1-404-362-61	TRANSFORMER, IF					
T4	1-406-498-11	COIL (OSC)					
		< VIBRATOR >					
X1	1-577-447-11	VIBRATOR, CERAMIC, 16.8MHz					
X2	1-577-448-11	VIBRATOR, CERAMIC, 17.9MHz					
X3	1-577-449-11	VIBRATOR, CERAMIC, 20.4MHz					
X4	1-577-445-11	VIBRATOR, CERAMIC, 22.64MHz					
X5	1-579-684-11	VIBRATOR, CRYSTAL, 26.025MHz					
X6	1-579-685-11	VIBRATOR, CRYSTAL, 28.525MHz					
X7	1-579-686-11	VIBRATOR, CRYSTAL, 32.35MHz					

Ref. No.	Part No.	Description	Remark
		MISCELLANEOUS	

ANT1	1-501-543-11	ANTENNA, TELESCOPIC	
SP1	1-544-758-11	SPEAKER (6.6CM)	

ACCESSORIES & PACKING MATERIALS

* 3-381-803-01 INDIVIDUAL CARTON
3-755-247-01 MANUAL, INSTRUCTION (TOURIST)
(JAPANESE/ENGLISH/KOREAN)
3-755-247-11 MANUAL, INSTRUCTION (ENGLISH/FRENCH/
SPANISH/PORTUGUESE/SWEDISH) (US, Canadian, AEP,
E. Australian)

3-755-247-41 MANUAL, INSTRUCTION (ENGLISH/GERMAN/
FRENCH/ITALIAN/DUTCH) (AEP, Germany, UK, Italian)
3-755-247-51 MANUAL, INSTRUCTION
(ENGLISH/ARABIC) (Saudi Arabia)
3-893-940-17 GUIDE, SHORT WAVE

3-383-148-01 CASE, CARRYING (AEP, Germany, UK, Italian,
E. Saudi Arabia, TOURIST, Australian)
3-383-735-01 CASE, CARRYING (US, Canadian)

[illegible][illegible]